# READ ME FIRST **TiCad** STAR

# Care:

The frame of your TiCad trolley is made of high-quality, rust-proof materials and has been sealed to keep out rain. The frame can be cleaned with a conventional household cleaning product – but **not** with abrasive cleaners. The titanium's shine can be restored with a special cleaning oil available from TiCad.

The hubs of the wheels and the connections **must not** be oiled or greased.

# WARRANTY

Your TiCad trolley has been designed and built with great care. Please get in touch with your specialist dealer or contact TiCad directly if you notice anything unusual. The provision of spare parts or repairs performed under warranty do not extend the warranty period. The warranty does not apply to damage caused by carelessness or rough handling, overloading the trolley, inappropriate operation, external force, submersion in water and unauthorised persons' actions. The warranty only applies if the enclosed operating instructions have been observed and the trolley is being appropriately used and cared for. Technical changes and new developments do not entitle warranty holders to upgrades.

The warranty period for the titanium frame and the wheels is 5 years from the date of purchase. The warranty does not apply to wear parts such as e.g. tyres, leather handle, fastening straps.

# SERVICE

If you experience any problems with your TiCad trolley, please first contact your specialist dealer or get in touch with us at our office in Altenstadt, Germany.

We will then arrange for your TiCad trolley to be collected and returned to us and help you with the packaging material. If you want us to perform an inspection or repair, we also offer to assist you directly without contacting your specialist dealer.

For trolleys located outside Germany, please always first contact your specialist dealer or contact us directly.

TiCad GmbH & Co. KG
Heegwaldstr. 3–5
D-63674 Altenstadt -Waldsiedlung
+49 (0)6047 / 987 90-14
+49 (0)6047 / 987 90-39
service@ticad.de

### Technical data and dimensions

Model	TiCad Star
Weight of frame + wheels	3.6 kg
Dimensions when folded	66x35x11cm

# PUBLISHER

TiCad GmbH & Co. KG, Heegwaldstr. 3–5, D-63674 Altenstadt www.ticad.de

The above information, wording and images have been largely standardised and are primarily intended to describe the trolley's basic functions. For this reason, the product supplied to you may slightly differ from the above descriptions, in particular if your trolley is a new version. This "Read Me First" manual must not be copied or used otherwise in whole or part without TiCad GmbH & Co. KG's consent.

Please carefully retain your Read Me First manual and the original packaging.

Please read our General Terms and Conditions of Business at www.ticad.de.

#### Concept & graphic implementation:

Bild, Satz und Sieg – Eugen-Kaiser-Straße 18, 63450 Hanau www.bild-satz-und-sieg.de









# TiCad®

# READ ME FIRST **TiCad** STAR







# **READ ME FIRST** TiCad STAR

## Congratulations!

You have chosen an excellent product manufactured by TiCad! All of our high-quality products are carefully handmade at our production facility in Altenstadt (Hessen, Germany).

To ensure that you will be able to enjoy your trolley for a very long time, please take some time to carefully read through these operating instructions, which contain important information that will make using your trolley a lot easier.

If you have any further questions regarding the use or care of your trolley, please contact your specialist dealer.


> We would like to wish you many enjoyable games of golf and a lot of success! Your TiCad team

# YOUR TICAD STAR IN DETAIL

- 1 Drawbar leather handle
- 2 Umbrella adapter
- 3 Drawbar
- 4 Drawbar adjuster
- 5 Fastening straps
- 6 Centre bar
- 8 Locking pin 9 Knurled sleeve

7 Shaft

- 10 Titanium wheel 11 Bottom bar



Shaft with locking pin groove



Removing and attaching the wheels



#### Attaching the golf bag:

To fasten the golf bag, insert one of the round fasteners into the strap of the opposite fastening strap. When doing so, make sure not to flick the fasteners, as this may cause injury. To undo the fastening straps, hold on to the bottom strap and then remove the top fastening strap with your other hand.

We recommend adjusting the drawbar only once the golf bag has been attached to prevent the trolley from tipping over.

# Adjusting the drawbar:

As soon as the golf bag has been attached to the TiCad trolley, you can adjust the drawbar to a comfortable height for you. You can loosen the drawbar by turning the black handle counter-clockwise 3 to 4 times. Only start moving the drawbar into the right position once it has been completely freed and moves without resistance. To fasten the drawbar, turn the black handle in the opposite direction. When doing so, move the drawbar slightly up and down to allow the fastening mechanism's teeth to fully engage with one another and to prevent them from becoming damaged.

Adjust the drawbar in such a way that the trolley is wellbalanced when pulled with the golf bag fitted in place.

# USING YOUR TROLLEY

Always move your TiCad trolley slowly and carefully when moving over rough ground that contains stones or potholes. Avoid kerb edges.

### Umbrella adapter:

l ockina pi

The umbrella adapter is supplied ready-fitted at the end of the drawbar's handle. To adjust the adapter to the drawbar's position and to your body height, loosen the screw in the centre of the adapter with the supplied Allen key and turn it into the required position.

When doing so, the larger hole on the adapter always has to point towards the top and the smaller hole with the thread to the bottom. Once you have adjusted the adapter, tighten the screw again.

# SETTING UP YOUR TROLLEY

# Fitting the shaft:

Before fitting the shaft, pull back the locking pin (black round handle) and turn it slightly to the right (about 45°). You can now insert the shaft halfway into the frame and release the locking pin by turning the black handle back again and allowing the locking pin to engage. You can now insert the shaft fully into the frame until it engages.

### Attaching the wheels:


The wheels can be attached and removed by pulling back the knurled sleeve. When attaching the wheels, slightly turning the sleeve can make it easier for the wheels to engage.

Always make sure that no dirt gets into the hub. The hubs must not be oiled or greased.

# Setting up your trolley:

The frame of your TiCad trolley is easy to set up and fold together. To unfold your trolley, push the bottom bar right down until it reaches the bottom limit stop and the centre bar right up until it reaches the top limit stop.

# TiCad®





Adjusting the drawbar



Allen screw in the umbrella adapter



Umbrella adapter with umbrella